Delcop End Feed Range



Conex | Bänninger
Delcop End Feed

Delcop End Feed capillary fittings are available in sizes 6-54mm and are suitable for connecting copper tubes in accordance with EN 1057.

Delcop End Feed fittings are designed for solder and brazing applications but, with the exception of Union fittings with copper tails, which can only be soft soldered. For sizes above 54mm please refer to the section on Delbraze.

Most fittings in the range are manufactured from copper or red brass thereby being immune to dezincification.

Hydraulic working temperatures and pressures based on EN 1254-1 are shown below:

Applications & Technical Information	
Drinking water	Y
Sanitary water	Y
Heating and chilled water systems	Y
Compressed air	Y
Gas	Y
Available Sizes	6-54mm
Operating Parameters solder 6-54mm	**Water** **Using Tin Silver 95/5%** 25 bar, 0°C to 30°C 25 bar @ 65°C 19 bar @ 95°C 16 bar @ 110°C **Using Tin Lead 50/50% or 60/40%** 16 bar, 0°C to 30°C 10 bar @ 65°C 7 bar @ 95°C 6 bar @ 110°C
Operating Parameters brazed 15mm	**Water** 35.1 bar, -20°C to 110°C 29.8 bar @ 150°C 15.8 bar @ 200°C
Material	Copper and Red Brass

For more detailes please contact our technical team.

SALES: +44 (0)121 557 2831 FAX: +44 (0)121 520 8778 WEB: www.conexbanninger.com EMAIL: sales@ibpgroup.com

END FEED ASSEMBLY INSTRUCTIONS:

Tools required:

Tube cutter, deburring tool, blow lamp, abrasive cloth, wire brush, lead free solder, flux.

Assembly

- Ensure the copper tube and fitting sizes are compatible. Cut the tube end square, and ensure it retains its shape.
- Deburr the tube, both inside and outside.
- Clean tube with an abrasive cloth, and fitting socket with a wire brush.
- Apply a thin layer of flux to the tube, and to the fitting socket.
- Insert the tube into the fitting until the tube stop is reached. Rotate the tube or fitting and remove any excess flux where possible.
- Light the blow lamp, and heat the fitting socket until the flux starts to boil. Keep the flame moving over the fitting and tube, do not provide excessive heat.
- Apply lead free solder to the tube-fitting interface until it fills the void.
- As a rule of thumb, a length of solder equivalent to the tube diameter will be adequate for a satisfactory joint.
- Remove the blow lamp, allow to cool and wipe the joint(s) with a damp cloth.
- Flush all residues out of the system.



Demounting

- This fitting system is not demountable.

Conex | Bänninger
Delcop End Feed

DC6012 Fitting Reducer

Male Copper x Copper



ITEM	SIZE	PACK	
5243 008006000	8 x 6mm	10	
5243 010006000	10 x 6mm	10	
5243 010008000	10 x 8mm	10	
5243 012008000	12 x 8mm	10	
5243 015008000	15 x 8mm	10	
5243 015010000	15 x 10mm	10	
5243 015012000	15 x 12mm	10	
5243 0220150005	22 x 15mm	25	A
5243 028015000	28 x 15mm	10	
5243 028022000	28 x 22mm	10	
5243 035015000	35 x 15mm	1	
5243 035022000	35 x 22mm	1	
5243 035028000	35 x 28mm	1	
5243 042015000	42 x 15mm	1	
5243 042022000	42 x 22mm	1	
5243 042028000	42 x 28mm	1	
5243 042035000	42 x 35mm	1	
5243 054015000	54 x 15mm	1	
5243 054022000	54 x 22mm	1	
5243 054028000	54 x 28mm	1	
5243 054035000	54 x 35mm	1	
5243 054042000	54 x 42mm	1	

*A range means fast moving products.

Conex | Bänninger
Delcop End Feed

DB6072LT Fitting Reducer

Male Copper x Copper



ITEM	SIZE	PACK
5243L015010000	15 x 10mm	10

DB601IM Imperial To Metric Adaptor

Male Copper (Imperial) x Copper (Metric)



ITEM	SIZE	PACK
5241 015004000	1/2 x 15mm	10
5241 022006000	3/4 x 22mm	10
5241 028008000	1 x 28mm	10

DB6012IM Imperial to Metric Adaptor

Male Copper (metric) x Copper (Imperial)



ITEM	SIZE	PACK
5242 022006000	3/4 x 22mm	25
5242 028008000	1 x 28mm	10

*A range means fast moving products.

SALES: +44 (0)121 557 2831 FAX: +44 (0)121 520 8778 WEB: www.conexbanninger.com EMAIL: sales@ibpgroup.com