Speedfit®

BRAIDED FLEXI HOSES

WRAS APPROVED PRODUCT

Not suitable for central heating.
Hot and cold water only, 6 Bar @ 65°C

SPEEDFIT X UNION NUT



	Part No.	Size mm x BSP	Bag Qty	Box Qty
150mm	FLX43P	15 x 1/2"	2	150
300mm	FLX34P	10 x 1/2"	2	150
	FLX35P	15 x 3/8"	2	150
	FLX15P	15 x 1/2"	2	100
	FLX16P	15 x 3/4"	2	100
	FLX22P	22 x 3/4"	2	100
500mm	FLX18P	15 x 1/2"	2	100
	FLX20P	15 x 3/4"	2	80
	FLX19P	22 x 3/4"	2	50
	FLX23P Full Bore	22 x 3/4"	2	40
1000mm	FLX40P	15 x 1/2"	1	20
	FLX42	15 x 3/4"	5	25
	FLX41P	22 x 3/4"	1	20

SPEEDFIT X SPEEDFIT



	Part No.	Size mm x mm	Bag Qty	Box Qty
300mm	FLX33P	15 x 10	2	150
	FLX17P	15 x 15	2	100
	FLX26P	22 x 22	2	60
500mm	FLX21P	15 x 15	2	100
	FLX27P	22 x 22	2	60
1000mm	FLX47	15 x 15	5	25

SPEEDFIT X MALE



	Part No.	Size mm x BSP	Bag Qty	Box Qty
300mm	FLX49	15 x 3/8"	25	100

ELBOW PATTERN



	Part No.	Size mm x BSP	Bag Qty	Box Qty
300mm	FLX36P	15 x 1/2"	2	100

SPEEDFIT X PLAIN STEM



	Part No.	Pipe mm	Stem mm	Bag Qty	Box Qty
300mm	FLX53	15	15	25	100

SPEEDFIT X UNION NUT WITH SERVICE VALVE ●



	Part No.	Size mm x BSP	Bag Qty	Box Qty
	Plastic Valves			
300mm	FLX37P	15 x 1/2"	2	100
	FLX39P	22 x 3/4"	2	50
	Plastic Valve with Handle			
300mm	FLX37-H	15 x 1/2"	2	100
	FLX39-H	22 x 3/4"	2	50

SPEEDFIT X SPEEDFIT WITH SERVICE VALVE ●



	Part No.	Size mm x mm	Bag Qty	Box Qty
	Brass Valve			
300mm	FLX44P	15 x 15	2	80
500mm	FLX45P	15 x 15	2	60

FOR MONOBLOC MIXERS



	Part No.	Size mm x male	Pack Qty	Box Qty
300mm	FLX48	12 x M10	2	100
	FLX28	15 x M10	2	100
	FLX29	15 x M12	2	100

BRAIDED FLEXI HOSES with Metal Connections

Not suitable for central heating.
Hot and cold water only, 10 Bar @ 85°C, 12.5 Bar @ 20°C

SPEEDFIT X UNION NUT WITH SERVICE VALVE ●



	Part No.	Size mm x BSP	Bag Qty	Box Qty
	Brass Valve			
300mm	FLX24P	15 x 1/2"	2	80
	FLX25P	22 x 3/4"	2	30
500mm	FLX31P	15 x 1/2"	2	50
	FLX38P	15 x 3/4"	2	50
	FLX32P	22 x 3/4"	2	30

1/4 Turn Valves. These valves have been designed to allow temporary servicing of downstream equipment and must only be used in the fully open or fully closed position.

Do Not use these Valves:
- In a partially open position to control flow.
- To provide a permanent termination.
- Without tubing assembled or plugged (or threaded connections sealed).
- As a tap or "faucet".

1/4 Turn Valves are indicated by this marker '●'